




ANTRIEBSELEMENTE

Installation and Operating Manual



V-Belt Drives | Motor Slide Rails | Foundation Blocks

If performance is required

www.luetgert-antriebe.de

INSTALLATION AND OPERATING MANUAL

V –BELT DRIVES


- All V-belts used should be manufactured in conformance with the relevant standards. Thoroughly remove any residues of oil and grease and other contamination. No traces of rust are permissible on the V-belt pulleys, especially in the area of the „V“ grooves.
- All V-belts used should be an original set of identical length. Avoid mixing V-belts of different manufacturers. The V-belts should have been stored free from damage and to the state of the art according to manufacturer's specifications. You can clean dirty V-belts with a mix of glycerine and spirit in the ratio of 1:10.
- It is important to install the V-belt pulleys parallel to the axis and aligned to each other. Make sure that pulley concentricity and run-out tolerance will not exceed the predefined limit values according to DIN 2211 or 2217 (also refer to Table 1).
- For installation, move the belt pulleys to each other until the V-belts can be mounted without using force. It is prohibited to use any aids, such as tyre levers or similar, since this might lead to damage of the V-belts.
- If you have mounted the V-belts conforming to the grooves, tighten the drive according to manufacturer's specifications. For this purpose, tighten the belt pulley, which can be moved parallel to the axis for tightening, by slowly turning the drive until the V-belt has reached the required initial tension. Always check the belt initial tension perpendicularly to the drawing part of the belt (load part) by means of appropriate strain gauge. Refer to Table 2 for the required amounts for initial tension, by using the impression depth mentioned on the continuation page of this Manual.
- After a first service period of approx. 0.5 to 2 hours, check the belt initial tension again and retighten, if required. After further approx. 20 operating hours under load, it is recommended to check and retighten again in order to compensate for the V-belt stretching during the start-up period.
- V-belt drives using high-capacity V-belts of standardized profile series are mainly maintenance-free during operation for their entire service lives. It is advisable to regularly inspect the belts and belt pulleys for any trace of damage and wear and tear.

Effective \varnothing	from to	50 100	106 160	170 250	280 400	450 630	710 1.000	1.120 1.600	1.800 4.000
Admissible pulley concentricity and run-out tolerance		0,2	0,3	0,4	0,5	0,6	0,8	1,0	1,2

Table No. 1

Profile	\varnothing Small pulley [mm]	Test force [N]	Deflection per 100 mm Length of freerunning part of belt
SPZ	63 - 180	25	2,3
SPA	90 - 140	50	3,2
	160 - 250		2,7
SPB	140 - 200	75	3,7
	224 - 400		2,7
SPC	224 - 315	125	3,2
	355 - 630		2,7

Table No. 2



L = Length of free-running part of belt
 F = Test force
 E_a = Deflection of free-running part of belt

Example of application:

Profile SPB

\varnothing Small pulley (e.g. motor pulley) = 180 mm
 Length of free-running part of belt = 460 mm
 Test force from the table = 75 N
 Deflection = $3,7 \times (460/100) = 17$ mm

INSTALLATION AND OPERATING MANUAL

TAPERLOCK-BUSHES

The **TaperLock Bush** system consists of conical clamping bushes with various bores in standardized sizes and the V-belt or flat belt pulleys with appropriately matched conical bore.

The advantages of the taper bush system are easy assembly and dismantling and the capacity of the belt pulleys to adapt to different bore diameters by exchanging the corresponding taper bush.

Assembly

- Clean all polished bush surface from grease, oil and dirt prior to assembly. Important surfaces are, in particular, the bore, the outside cone of the bush and all semi-bores and semi-thread bores. Also degrease the conical bore of the belt pulley.
- Fit the taper bush on to the hub of the pulley until the specific split-bores in the hub and in the bush coincide. Make sure that every thread (half-thread) in the bush corresponds to a smooth half-bore in the hub and vice versa. The fastening screws for the bush included in the supply are slightly lubricated with oil on the thread, pointed end to the bottom and manually screwed into the provided holes. Further keep in mind that the fastening bores are those, which are provided with a half-thread in their hubs.
- Now push the belt pulley unit with the pre-assembled taper bush to its correct position on the shaft. When using a key scat, insert key first into keyway of shaft prior to assembling the bush. Only use keys supporting on their flanks. Now tighten the fastening screws of the bush uniformly and step-by-step with the help of a torque wrench until reaching the recommended starting torque according to Table No. 3, in order to prevent any clamping between bush and pulley. Make sure that, at first, the bush is clamped on the shaft, and that the hub slides into its end position only afterwards. With light blows of a hammer on a sleeve or a wooden block, you can drive down the clamping bush into the cone to slightly increase the clamping effect. After that, the screws can be tightened until the recommended starting torque is obtained. Never exceed the starting torques mentioned in the assignment table
- With perpendicular shaft arrangement and particularly rough operation (shock load), further safety precautions should be taken to prevent any movement of the taper clamping bush on the shaft.
- Empty bores are filled with grease to avoid penetration of dirt or foreign substances. After a running in period of the drive under load, it is recommended to check the fastening screws of the taper clamping bush.

INSTALLATION AND OPERATING MANUAL

TAPERLOCK-BUSHES

Dismantling

For dismantling, loosen all the fastening screws of the taper bush degrease the bores filled with lubricant. Degrease the pull-off bores, up to 2 items according to the bush size each, and slightly lubricate them with oil. You can recognize the pull-off from the fact that the relevant half-threads are located on the bush side.

- The screws are screwed into the pull-off bores and steadily tightened until the taper bush comes free from the hub and is freely moveable on the shaft.
- The parts can now be removed from the shaft.

Bush Nr.	Bush bore [mm]	Theoretical slip torque without key [Nm]	Recommended screw tightening torque, max [Nm]
1210	16	82	15
	19	105	
	24	142	
	32	210	
1610 1615	19	98	15
	24	135	
	38 42	240 265	
2012	24	165	25
	38	310	
	42	340	
	48	400	
	50	420	
2517	24	220	35
	38	380	
	42	430	
	48	510	
	55	600	
	60	670	
3020 3030	38	520	70
	48	730	
	55	890	
	60	970	
	75	1300	
3535 3525	42	1000	85
	60	1580	
	75	2150	
	90	2600	
4040 4030	48	1700	120
	60	2150	
	75	3150	
	100	4400	
4545 4535	55	2500	140
	75	3900	
	100	5500	
	110	6300	
5050 5040	75	3950	200
	100	5650	
	125	7370	
6050	100	8950	550
	125	11900	
	150	14900	
7060	125	15600	550
	150	19400	
	175	23200	

Tightening and slip torques for taper bushes

The indicated slip torques for the corresponding tightening torques were determined on the test bench for the respective bore \varnothing and theoretical values for friction type connection without key. If impact loading occurs then the slip torque should be divided by 2.

In principle it is recommended that the bush to shaft connection is always made with a key. The recommended tightening torques should not be exceeded and are sufficient to secure the connection between the shaft and the bore against axial slip during normal operation.

For impact-loaded, vibrating or suspended operation, an additional mechanical retaining device should be fitted to prevent slippage or creeping on the shaft.

PROBLEM- / SOLUTION TABLE

BELTS

	Problem	Possible Cause	Remedy
PREMATURE BELT FAILURE	Broken belt(s)	Insufficiently rated drive Belt is rolled or levered on pulley Foreign body dropped into drive Extreme shock load	New calculation required On assembly, use retightening option Install suitable safety device or drive protection New calculation to adapt to shock load
	Belt(s) do(es) not resist load (creep); no visible cause	Insufficiently rated drive Tension assembly damaged Worn-out pulley grooves Movement axle distance	New calculation required Keep to correct assembly method Check groove wear, replace, if required Check drive for axle distance movement during operation
	Failure lateral assembly	Non-aligning pulleys Tension assembly damaged	Check and correct alignment Keep to correct assembly method
	Belt spalling and substructure detaching	Pulley too small Tension assembly damaged	Check drive design, use larger pulleys Increase diameter of outer tightening roller accordingly
STRONG OR UNUSUAL BELT WEAR	Wear on the upper belt edge	Friction on safeguarding equipment Malfunction of tightening roller Incorrect belt pulley seat (belt too small for groove)	Replace or repair safety equipment Replace the tightening roller Use the correct belt-pulley combination
	Wear on flanges	Belt creep Non-alignment Worn-out pulleys Wrong belt	Retighten until creep is gone Realign pulleys Replace pulleys Replace by correct belt size
	Wear on lower belt shell	Incorrect belt-pulley seat Worn-out pulleys	Use the correct belt-pulley combination Replace pulleys
	Wear on lower belt shell	Belt substructure on pulley groove (belt too small for groove) Worn-out grooves Dirty pulleys	Use the correct belt-pulley combination Replace pulleys Clean pulleys
	Crack formation in substructure	Pulley diameter too small Belt creep Outer tightening roller too small Incorrect storage	Use larger pulley diameter Retightening Use larger diameter for outer tightening roller Do not stretch belt too tight, do not bend or inflect. Avoid heat and direct sunlight

PROBLEM- / SOLUTION TABLE

BELTS

	Problem	Possible Cause	Remedy
STRONG OR SUUNUAL BELT WEAR	Burned out and hard edges and substructure	Belt creep Worn-out pulleys Insufficiently rated drive Wavy movement	Retighten until creep is gone Replace the pulleys New calculation of drive Check if there are any changes in the axle distance
	Extreme hardening of belt shell	Hot environment of belt	Improve drive ventilation
	Flaky, sticky or swollen belt surface	Pollution through oil or chemicals at belts or in the pulleys	Do not use belt stretching agents; remove oil, grease or chemicals
V- BELTS TWIST OR JUMP OFF THE DRIVE	Individual or composite belts	Shock load or vibration Foreign substances in pulley grooves Non-aligned pulleys Worn-out pulley grooves Traction body damaged Wrong position of flat tightening roller Wrong belt set Inappropriate drive design	Check drive design, Shield grooves and drive New alignment of the pulleys Replace pulleys Use correct assembly and storage Procedures Carefully insert flat tightening roller into loose part of belt, as close as possible to the driving pulley Replace with new belt set Do not mix old and new belts Check stability, axle distance and means of reducing vibration
BELT EXTENSIOND BEYOND RETIGHTENING VALU	Composite belts will not extend uniformly	Non-aligned drive Dirty pulleys Broken traction body or damaged Substructure Wrong belt set	Realign and retighten drive Clean pulleys Replace all belts, assemble properly Assembly the correct belt set
	Individual belts or all belts expand in the same way	Not sufficient clearance for retightening High overloaded or not sufficiently rated drive Broken traction bodies	Check the amount of retightening Recalculation of the drive Replacement of belts, correct assembly
NOISE CAUSED BY BELTS	Whistling or "chirping"	Belt creep Dirt	Retightening required Clean belt and pulleys
	Whipping noise	Loose belt Flat belt set Non-alignment	Retightening required Insert correct belt set New alignment of pulleys, so that all pulleys are equally loaded
	Grinding noise	Safety equipment is in grinding contact	Repair, replacement or new design of safety equipment

PROBLEM- / SOLUTION TABLE

BELTS

	Problem	Possible Cause	Remedy
NOISES CAUSED BY BELT	Grinding noise	Bearings are damaged	Replace, align and grease
	Unusually loud drive	Wrong belt Worn-out pulleys Dirt on grooves	Use correct belt size Replace pulleys Clean pulleys, improve protection Remove rust, colour or dirt from grooves
VIBRATIONS	Fluttering belts	Tension of belt is too low Wrong belt sets Non-alignment of pulleys	Retighten Assemble new belt set Alignment of pulleys
	Excessive vibration in drive system	Wrong belt Unsuitable design of machinery or equipment Pulleys jumped out Loose drive components	Use proper belt profile section for each pulley Check structure and clips for correct tightness Replace pulley Check all machine parts, safety equipment, motor supports, motor padding, bushes, clips and housing for stability, appropriate construction thickness, correct maintenance and assembly
FAULTS WITH COMPOSITE V-BELTS	Cover band coming off	Worn-out pulleys Wrong groove space	Replace pulleys Measure pulley grooves and replace with standard pulleys
	Worn-out or damaged cover band of belt	Safety equipment is obstructed Malfunction or damage of outer tightening roller	Check safety equipment Repair or replace outer tightening roller
	Composite belt comes off the drive	Dirty pulleys	Clean grooves Use individual belts to avoid dirt collecting in the grooves
	One or several ribs are miss tracking outside the pulley	Non-alignment Tension is too low	New alignment of drive Retighten

PROBLEM- / SOLUTION TABLE

BELTS / PERIPHERIE

	Problem	Possible Cause	Remedy
FAULTS WITH PULLEYS	Broken or damaged pulley	Wrong assembly of pulleys	Do not tighten bush bolts beyond recommended torques
		Wrong assembly of belts	Do not lever belts onto pulleys
		Excessive circumferential speed	Keep circumferential speed of pulleys below recommended maximum limits
	Pollution	Foreign body in the drive	Use appropriate protection for drive
Excessive wear of grooves	Excessive tension of belts	Retighten, check drive design	
	Sand, dirt or other pollution	Clean and protect the drive to the optimum extent	

	Problem	Possible Cause	Remedy
FAULTS WITH DRIVE	Bent or broken shaft	Extreme overstrain of belts	Retighten
		Over-dimensioned drive*	Check drive design, mount smaller belts or fewer belts if required
Accidental damage		Recalculation of safety equipment	
Safety equipment damaged	Damage by error or inappropriate design of safety equipment	Error of machine design	Check machine design
		Repair, design for longer life	
HOT STORE	Over-tightened drive belt	Worn-out grooves, belt makes contact, but no power is transmitted unless it is over tightened	Replace pulleys
		Wrong tension	Tighten the drive properly Retighten
	Diameter of pulley too small	Diameters of pulleys advised by motor manufacturer were not observed	Recalculation of drive
	Bad condition of bearings	Over-dimensioned bearings	Check bearing
		Insufficient maintenance of bearings	Align and lubricate bearings
Pulleys are seated on shaft too close to the front	Error or obstacle	Position the pulleys as close as possible to bearings Eliminate obstacles	
Belt creep	Tension of drive is too small	Retighten	


* Too many drive belts or too wide ones can adversely affect the motor or driving shafts. This may occur if load requirements for a drive are reduced, but the belts are not recalculated accordingly. This can also occur by calculation of too high loads for belts. The forces arising due to belt tension will be too high for those shafts.

INSTALLATION MANUAL


FOUNDATION BLOCKS

Regarding their functional dimensions, the foundation blocks are conforming to DIN 799. They are manufactured of the material EN-GJL 200 in accordance with DIN EN 1561.

For installation, use foundation blocks without any paint. Prepare openings in the cement floor in specified sizes referring to DIN 799 where the foundation blocks can be sealed. To prevent concrete or mortar from penetrating into the threads, seal them or fill them with grease. For pouring the openings, use concrete of the same solidity and granulation classes as for the surrounding concrete surfaces.



D1	L1	D3	D5	L2	L3	m1	m2
M 10	125	56	M 8	35	20	8	16
M 12	150	72	M 12	40	22	10	20
M 16	180	85		50	25	12	
M 20	200	100		56	28	14	
M 24	250	125	M 16	70	36	18	25
M 30	280	140		79	40	20	30
M 36	340	180	M 20	100	50	25	25
M 42	425	225		120	60	28	30
M 48	475	250	M 24	129	64	30	32



Form A
Standard shape without side casting lug (cam)

Form B
Version with lug (cam) for thread and adjusting screw

INSTALLATION AND OPERATING MANUAL

MOTOR SLIDE RAILS

1. Quality

Slide rail made of material: EN-GJL-200 according to DIN 1561. Fastening screws for the machine, as well as straining screws, are included in the supply.

Concrete fixing bolts with hexagonal nut for anchoring are to be ordered separately.

2. Safety Precautions

Screws coming loose are very dangerous. Always make sure that you keep to the prescribed starting torques for the screws, and to check them regularly.

Never carry out adjusting work with the machine running. Make sure to lock the main switch of the machine against unintentional restarting.

3. Mounting the Slide Rail


When fastening the slide rails to foundations, check, prior to tightening the concrete fixing bolts, the concrete base should be set firm according to the specified setting period.

When fastening the slide rails on frames, plates and such, use rails with machined base surface in order to avoid breakage due to distortion. All contact surfaces should be even and properly aligned.

The connecting screws may not turn themselves; there must be enough space for the wrench.

3.1 Arrangement of Slide Rails

Keep to the motor foot distance X. Arrangement of slide rails acc. to Fig. 1. Make sure that the slide rails are placed in parallel. Maximum parallel deviation should not exceed $X \pm 1\text{mm}$. The height relating to each other can be checked with a spirit level.



1 Motor slide rail
2 Tightening screw
3 Fastening screw and nut




Fig. 1

INSTALLATION AND OPERATING MANUAL

MOTOR SLIDE RAILS

3.2 Slide Rail Design




Fig. 2

Lightweight version A up to 650 mm and DIN 42923–version up to 500 mm




Fig. 3

Lightweight version B up to 700 - 1500 mm and DIN 42923–version from 630 up to 1000 mm




Fig. 4

Lightweight version C from 1600 - 2200 mm and DIN 42923–version up to 1250 mm




Fig. 5

Heavy version WEN 40.003

4. Fastening the Motor

Place the motor on the slide rail and tighten the fastening nut checking that the motor still remains moveable. Accurately align the motor by means of the straining screws. With flat belt drives or chain drives, adjust the required initial tension (keep to supplier's instruction). Then firmly tighten the fastening nuts.

PRODUCT OVERVIEW

EXCERPT

Drive pulleys

V-belt pulleys | V-belt pulleys | Flywheels | Grid pulleys | Timing belt pulleys | Rubberized Pulleys | Split pulleys | Aluminium pulley



Supplies for drive belts

TaperLock clamping bushes | Motor mounting systems | V-belts / Drive belts | V-belt metrology | Rubber suspension units | Oscillating mountings | Tensioner devices | Foundation blocks | Shafts and rolls



More information required?

www.luetgert-antriebe.de

